Name: Seshasai.PB Reg NO: 21MIA1005

Image and Video Analytics Assignment 2

Lab Task 1: Setup and Basic Extraction

Objective:

Install the necessary tools and libraries, and extract frame information from a video.

Steps:

- 1. Install ffmpeg and ffmpeg-python:
 - o Install the ffmpeg tool and the ffmpeg-python library.
- 2. Extract Frame Information:
 - o Extract frame information from a sample video.

Code:

```
import sys

import ffmpeg

sys.path.append(r'C:\ffmpeg')

input_file = 'in.mp4'


output_pattern = 'frames/frame_%04d.jpeg'

ffmpeg.input(input file).output(output pattern).run()
```

my spyder console is not recognizing 'ffmpeg' I'm running it in 'command prompt'

D:\Sem7\Image and video analytics\Lab\lab2>python lab.py

So after running this we get our frames



To get information about each frame we can run this prompt in cmd

```
D:\Sem7\Image and video analytics\Lab\lab2>ffprobe -show_frames in.mp4
```

This will display information about each frame

```
color_space=bt709
color_primaries=bt709
color_transfer=bt709
chroma_location=left
[/FRAME]
[FRAME]
media_type=video
stream_index=0
key_frame=0
pts=526
pts_time=21.040000
pkt_dts=N/A
pkt_dts_time=N/A
best_effort_timestamp=526
best_effort_timestamp_time=21.040000
duration=1
duration_time=0.040000
pkt_pos=56529996
pkt_size=197937
width=3840
height=2160
crop_top=0
crop_bottom=0
crop_left=0
crop_right=0
pix_fmt=yuv420p
sample_aspect_ratio=N/A
pict_type=P
interlaced_frame=0
top_field_first=0
repeat_pict=0
color_range=tv
color_space=bt709
color_primaries=bt709
color_transfer=bt709
chroma_location=left
[/FRAME]
[FRAME]
media_type=video
```

Lab Task 2: Frame Type Analysis

Objective:

Analyze the extracted frame information to understand the distribution of I, P, and B frames in a video

Steps:

1. Modify the Script:

- o Count the number of I, P, and B frames.
- Calculate the percentage of each frame type in the video.

2. Analyze Frame Distribution:

- o Plot the distribution of frame types using a library like matplotlib.
- Plot a pie chart or bar graph showing the distribution of frame types using matplotlib.

To get type of frame information, Enter

```
D:\Sem7\Image and video analytics\Lab\lab2>ffprobe -show_frames in.mp4 | findstr "pict_type"
```

This will display type of each frame

```
pict_type=I
pict_type=B
pict_type=B
pict_type=B
pict_type=P
```

We can extract this and information to analyse and visualize the frames to get information

```
frame_types =["]
I"
, "B"
,"P"
, "B"
,"P"
, "B"
```

```
,"P"
, "B"
,"B"
,"B"
,"B"
, "B"
,"B"
,"P"
,"P"
,"I"
,"B"
, "B"
, "B"
,"B"
,"B"
, "B"
,"P"
, "B"
, "B"
```

```
, "B"
,"P"
,"B"
, "B"
,"B"
,"B"
,"P"
, "B"
,"P"
,"P"
,"P"
, "B"
,"B"
, "B"
, "B"
, "B"
,"B"
,"P"
, "B"
, "B"
```

```
,"P"
, "B"
,"B"
,"B"
,"I"
,"B"
, "B"
, "B"
,"B"
,"P"
,"B"
,"P"
,"P"
, "B"
,"P"
,"B"
,"B"
,"B"
,"P"
```

```
, "B"
, "B"
,"P"
,"B"
,"B"
,"B"
,"B"
,"P"
, "B"
,"B"
,"P"
,"P"
,"B"
, "B"
,"P"
, "B"
, "B"
```

```
, "B"
,"P"
,"B"
, "B"
,"B"
,"P"
, "B"
,"P"
,"P"
,"P"
,"P"
,"B"
,"P"
,"P"
, "B"
,"P"
,"B"
,"B"
, "B"
```

```
,"P"
, "B"
,"B"
,"B"
, "B"
, "B"
, "I"
, "B"
,"P"
, "B"
,"P"
, "B"
,"B"
,"B"
,"B"
,"B"
,"P"
, "B"
```

```
, "B"
,"P"
, "B"
,"P"
,"B"
,"P"
,"B"
,"B"
, "B"
,"P"
,"B"
,"B"
, "B"
, "B"
,"P"
,"B"
,"P"
,"B"
,"B"
, "B"
```

```
,"P"
,"I"
,"B"
,"B"
,"B"
,"B"
, "B"
,"P"
,"P"
,"P"
,"P"
,"B"
,"P"
,"P"
,"B"
,"P"
,"B"
,"B"
, "B"
```

```
,"P"
, "B"
,"B"
,"B"
, "B"
, "B"
,"B"
,"P"
,"B"
,"B"
, "B"
, "B"
,"B"
,"B"
,"B"
,"P"
, "B"
, "B"
```

```
, "B"
,"P"
,"B"
, "B"
,"B"
, "B"
,"B"
,"B"
, "B"
,"P"
,"B"
,"P"
,"P"
, "B"
,"P"
,"B"
,"B"
, "B"
```

```
"P"]
frame counts = {'I': 0, 'P': 0, 'B': 0}
for frame type in frame types:
   if frame type in frame counts:
        frame counts[frame type] += 1
total frames = len(frame types)
frame percentages = {ftype: (count / total frames) * 100 for ftype,
count in frame counts.items() }
# Print the results
print(f"Frame Counts: {frame counts}")
print(f"Frame Percentages: {frame percentages}")
import matplotlib.pyplot as plt
def plot distribution(frame counts, frame percentages):
   plt.figure(figsize=(12, 6))
   plt.subplot(1, 2, 1)
    plt.pie(frame counts.values(), labels=frame counts.keys(),
autopct='%1.1f%%')
    plt.title('Frame Type Distribution (Pie Chart)')
    plt.subplot(1, 2, 2)
   plt.bar(frame_counts.keys(), frame_counts.values(), color=['red',
   plt.xlabel('Frame Type')
   plt.ylabel('Count')
    plt.title('Frame Type Distribution (Bar Graph)')
   plt.tight layout()
   plt.show()
```


plot distribution(frame counts, frame percentages)

Output:

Frame Counts: {'I': 7, 'P': 135, 'B': 386}

Frame Percentages: {'I': 1.3257575757575757, 'P': 25.568181818181817, 'B':

73.10606060606061}



Lab Task 3: Visualizing Frames

Objective:

Extract actual frames from the video and display them using Python.

Steps:

1. Extract Frames:

- o Use ffmpeg to extract individual I, P, and B frames from the video.
- o Save these frames as image files.

2. **Display Frames**:

 Use a library like PIL (Pillow) or opency-python to display the extracted frames.

Tasks:

- 1. Save I, P, and B frames as separate image files using ffmpeg.
- 2. Use PIL or opency-python to load and display these frames in a Python script.
- 3. Compare the visual quality of I, P, and B frames.

```
frames dir = './frames/' # Adjust this path as needed
for i, frame type in enumerate(frame types):
    original filename = f"frame {i+1:04d}.jpeg"
    new filename = f"{frame type} frame {i+1:04d}.jpeg"
    original_path = os.path.join(frames dir, original filename)
    new_path = os.path.join(frames_dir, new filename)
    if os.path.exists(original path):
        os.rename(original path, new path)
        print(f"File {original filename} does not exist in the
import cv2
import matplotlib.pyplot as plt
def display frames(frame paths):
    for path in frame paths:
        image = cv2.imread(path)
        image rgb = cv2.cvtColor(image, cv2.COLOR BGR2RGB)
        plt.imshow(image rgb)
        plt.title(f"Frame: {os.path.basename(path)}")
        plt.axis('off')
       plt.show()
example I frame = os.path.join(frames dir, 'I frame 0001.jpeg')
example_P_frame = os.path.join(frames_dir, 'P_frame_0005.jpeg')
example B frame = os.path.join(frames dir, 'B frame 0002.jpeg')
display frames([example I frame, example P frame, example B frame])
```

Quality comparison of different image types:


Frame: I_frame_0001.jpeg



Frame: P_frame_0005.jpeg



Frame: B_frame_0002.jpeg



Lab Task 4: Frame Compression Analysis

Objective:

Analyze the compression efficiency of I, P, and B frames.

Steps:

- 1. Calculate Frame Sizes:
 - o Calculate the file sizes of extracted I, P, and B frames.
 - Compare the average file sizes of each frame type.
- 2. Compression Efficiency:
 - o Discuss the role of each frame type in video compression.
 - o Analyze why P and B frames are generally smaller than I frames.

```
# Directory containing the renamed frames
frames_dir = './frames/'

# Initialize dictionaries to store sizes and counts
frame_sizes = {'I': [], 'P': [], 'B': []}

# Calculate the file sizes
for filename in os.listdir(frames_dir):
    if filename.startswith('I_') or filename.startswith('P_') or
filename.startswith('B_'):
        frame_type = filename.split('_')[0]
        file_path = os.path.join(frames_dir, filename)
        file_size = os.path.getsize(file_path)
        frame_sizes[frame_type].append(file_size)

# Calculate average sizes
average_sizes = {frame_type: sum(sizes) / len(sizes) if sizes else 0
for frame_type, sizes in frame_sizes.items()}

# Print out the results
print("Average File Sizes (bytes):")
for frame_type, avg_size in average_sizes.items():
    print(f"{frame_type}: {avg_size:.2f} bytes")
```

Output:

```
Sem7/Image and video analytics/Lab/lab2')
Average File Sizes (bytes):
I: 225845.00 bytes
P: 198026.24 bytes
B: 196880.56 bytes
```

Analysis

These results align more closely with typical expectations, where I-frames are larger than P-frames and B-frames:

- 1. **I-Frames** are expected to be larger because they store a complete image without reference to other frames.
- 2. **P-Frames** are smaller than I-frames as they only store differences from previous frames, using predictive coding.
- 3. **B-Frames** are usually the smallest, leveraging both past and future frames to encode differences with high efficiency.

Lab Task 5: Advanced Frame Extraction

Objective:

Extract frames from a video and reconstruct a part of the video using only I frames.

Steps:

- 1. Extract and Save I Frames:
 - o Extract I frames from the video and save them as separate image files.
- 2. Reconstruct Video:
 - o Use the extracted I frames to reconstruct a portion of the video.
 - o Create a new video using these I frames with a reduced frame rate.

```
import cv2
import os


# Path to the directory containing I frames
i_frame_dir = './I_frames/' # Update this path as needed
output_video_path = 'reconstructed.mp4' # Output path for the
reconstructed video

# Define frame rate (we'll use 3.5 fps for at least 2 seconds duration)
frame_rate = 3.5
num_frames = 7
```

```
frame files = [f for f in sorted(os.listdir(i frame dir)) if
f.startswith('I frame ')]
if len(frame files) != num frames:
    print(f"Error: Expected {num frames} frames, found
{len(frame files)}.")
    first frame = cv2.imread(os.path.join(i frame dir, frame files[0]))
    height, width, layers = first frame.shape
    fourcc = cv2.VideoWriter fourcc(*'mp4v') # Codec for .mp4 files
    video writer = cv2.VideoWriter(output video path, fourcc,
frame rate, (width, height))
    for frame file in frame files:
        frame path = os.path.join(i frame dir, frame file)
        frame = cv2.imread(frame path)
    video writer.release()
    print(f"Video created successfully and saved as
{output video path}")
```

Output:

D:\Sem7\Image and video analytics\Lab\lab2>python lab6.py Video created successfully and saved as reconstructed.mp4



Lab Task 6: Compare the quality of images using PSNR, SSIM, MSE

PSNR

Code:

```
from math import log10, sqrt
import cv2
import numpy as np

def PSNR(original, compressed):
    mse = np.mean((original - compressed) ** 2)
    if(mse == 0):
        return 100
    max_pixel = 255.0
    psnr = 20 * log10(max_pixel / sqrt(mse))
    return psnr

def main():
    original = cv2.imread("./frames/I_frame_0001.jpeg")
    compressed = cv2.imread("./frames/B_frame_0002.jpeg", 1)
    value = PSNR(original, compressed)
    print(f"PSNR value is {value} dB")

if __name__ == "__main__":
    main()
```

Output:

```
In [4]: runfile('D:/Sem7/Image and video analytics/Lab/lab2/task6_PSNR.py',
wdir='D:/Sem7/Image and video analytics/Lab/lab2')
PSNR value is 36.325366048378825 dB
```

SSIM

```
import torch
import torch.nn.functional as F
import numpy as np
import math
from PIL import Image
import cv2
def gaussian(window size, sigma):
distribution with standard
    gauss = torch.Tensor([math.exp(-(x -
window size//2)**2/float(2*sigma**2)) for x in range(window size)])
    return gauss/gauss.sum()
gauss dis = gaussian(11, 1.5)
print("Distribution: ", gauss dis)
print("Sum of Gauss Distribution:", torch.sum(gauss dis))
def create window(window size, channel=1):
    1d window = gaussian(window size=window size,
sigma=1.5).unsqueeze(1)
    2d window =
1d window.mm( 1d window.t()).float().unsqueeze(0).unsqueeze(0)
    window = torch.Tensor( 2d window.expand(channel, 1, window size,
window size).contiguous())
    return window
window = create window(11, 3)
print("Shape of gaussian window:", window.shape)
```

```
def ssim(img1, img2, val range, window size=11, window=None,
size average=True, full=False):
    L = val range # L is the dynamic range of the pixel values (255 for
    pad = window size // 2
        _, channels, height, width = img1.size()
        channels, height, width = img1.size()
    if window is None:
       real size = min(window size, height, width) # window should be
        window = create window(real size,
channel=channels).to(img1.device)
    mu1 = F.conv2d(img1, window, padding=pad, groups=channels)
    mu2 = F.conv2d(img2, window, padding=pad, groups=channels)
   mu1 sq = mu1 ** 2
   mu2 sq = mu2 ** 2
    mu12 = mu1 * mu2
    sigma1 sq = F.conv2d(img1 * img1, window, padding=pad,
groups=channels) - mu1 sq
    sigma2_sq = F.conv2d(img2 * img2, window, padding=pad,
groups=channels) - mu2 sq
    sigma12 = F.conv2d(img1 * img2, window, padding=pad,
groups=channels) - mu12
    contrast_metric = (2.0 * sigma12 + C2) / (sigma1_sq + sigma2_sq +
C2)
```

```
numerator1 = 2 * mu12 + C1
    numerator2 = 2 * sigma12 + C2
    denominator1 = mu1 sq + mu2 sq + C1
    denominator2 = sigma1 sq + sigma2 sq + C2
denominator2)
    if size average:
    if full:
    return ret
load images = lambda x: np.asarray(Image.open(x).resize((480, 640)))
# Helper functions to convert to Tensors
tensorify = lambda x: torch. Tensor(x.transpose((2, 0,
1))).unsqueeze(0).float().div(255.0)
def display_imgs(x, transpose=True, resize=True):
    if resize:
        x = cv2.resize(x, (400, 400))
    if transpose:
    cv2.waitKey(0)
    cv2.destroyAllWindows()
img1 = load images("./frames/I frame 0001.jpeg")
img2 = load images("./frames/B frame 0002.jpeg")
noise = np.random.randint(0, 255, (640, 480, 3)).astype(np.float32)
```

```
noisy_img = img1 + noise
   _img1 = tensorify(img1)
   _img2 = tensorify(img2)
true_vs_false = ssim(_img1, _img2, val_range=255)
print("True vs False Image SSIM Score:", true_vs_false)

# Check SSIM score of True image vs Noised_true Image
   _img1 = tensorify(img1)
   _img2 = tensorify(noisy_img)
true_vs_false = ssim(_img1, _img2, val_range=255)
print("True vs Noisy True Image SSIM Score:", true_vs_false)

# Check SSIM score of True image vs True Image
   _img1 = tensorify(img1)
true_vs_false = ssim(_img1, _img1, val_range=255)
print("True vs True Image SSIM Score:", true_vs_false)
```

Output:

```
em7\Image and video analytics\Lab\lab2>python task7.
Distribution: tensor([0.0010, 0.0076, 0.0360, 0.1094, 0.2130, 0.2660, 0.2130, 0.1094, 0.0360,
         0.0076, 0.0010])
Sum of Gauss Distribution: tensor(1.)
Shape of gaussian window: torch.Size([3, 1, 11, 11])
D:\Sem7\Image and video analytics\Lab\lab2\task7.py:105: UserWarning: The given NumPy array is not writable, and PyTorch does not support non-writable tenso
rs. This means writing to this tensor will result in undefined behavior. You may want to copy the array to protect its data or make it writable before conve
rting it to a tensor. This type of warning will be suppressed for the rest of this program. (Triggered internally at ..\torch\csrc\utils\tensor_numpy.cpp:21
  tensorify = lambda x: torch. Tensor(x.transpose((2, 0, 1))).unsqueeze((0).float().div((255.0))
True vs False Image SSIM Score: tensor(0.9795)
D:\Sem7\Image and video analytics\Lab\lab2>python task7.py
Distribution: tensor([0.0010, 0.0076, 0.0360, 0.1094, 0.2130, 0.2660, 0.2130, 0.1094, 0.0360,
         0.0076, 0.0010])
Sum of Gauss Distribution: tensor(1.)
Shape of gaussian window: torch.Size([3, 1, 11, 11])
D:\Sem7\Image and video analytics\Lab\lab2\task7.py:105: UserWarning: The given NumPy array is not writable, and PyTorch does not support non-writable tenso rs. This means writing to this tensor will result in undefined behavior. You may want to copy the array to protect its data or make it writable before conve
rting it to a tensor. This type of warning will be suppressed for the rest of this program. (Triggered internally at ..\torch\csrc\utils\tensor_numpy.cpp:21
 tensorify = lambda x: torch. Tensor(x.transpose((2, 0, 1))).unsqueeze(0).float().div(255.0)
True vs False Image SSIM Score: tensor(0.9795)
True vs Noisy True Image SSIM Score: tensor(0.0573)
True vs True Image SSIM Score: tensor(1.)
D:\Sem7\Image and video analytics\Lab\lab2>python task6_SSIM.py
Distribution: tensor([0.0010, 0.0076, 0.0360, 0.1094, 0.2130, 0.2660, 0.2130, 0.1094, 0.0360,
         0.0076, 0.0010])
Sum of Gauss Distribution: tensor(1.)
Shape of gaussian window: torch.Size([3, 1, 11, 11])
D:\Sem7\Image and video analytics\Lab\lab2\task6_SSIM.py:105: UserWarning: The given NumPy array is not writable, and PyTorch does not support non-writable
tensors. This means writing to this tensor will result in undefined behavior. You may want to copy the array to protect its data or make it writable before
converting it to a tensor. This type of warning will be suppressed for the rest of this program. (Iriggered internally at ..\torch\csrc\utils\tensor_numpy.c
 tensorify = lambda x: torch.Tensor(x.transpose((2, 0, 1))).unsqueeze(0).float().div(255.0)
True vs False Image SSIM Score: tensor(0.9795)
 True vs Noisy True Image SSIM Score: tensor(0.0572)
True vs True Image SSIM Score: tensor(1.)
```

MSE:

```
import numpy as np
from PIL import Image
import cv2
def mse(imageA, imageB):
    # Ensure the images are numpy arrays
    imageA = np.array(imageA)
    imageB = np.array(imageB)

    # Check if the images have the same shape
    if imageA.shape != imageB.shape:
        raise ValueError("Input images must have the same dimensions.")

# Compute the MSE
    err = np.sum((imageA.astype("float") - imageB.astype("float")) **
2)
    err /= float(imageA.shape[0] * imageA.shape[1] * imageA.shape[2])
    return err

# Load images using the provided helper functions or directly with cv2
or PIL
img1 = cv2.imread("./frames/I_frame_0381.jpeg")
img2 = cv2.imread("./frames/B_frame_0002.jpeg")

# Calculate MSE
mse_value = mse(img1, img2)
print(f"MSE between the images: {mse_value}")
```

Output:

```
In [5]: runfile('D:/Sem7/Image and video analytics/Lab/lab2/task6_MSE.py',
wdir='D:/Sem7/Image and video analytics/Lab/lab2')
MSE between the images: 2022.4889285542054
```